

I N S T A L L A T I O N I N S T R U C T I O N S

- Use YorkShield 106 PT with polypropylene side out for isolation of hangers and galvanized hardware.
 - Install as you would any conventional aluminum or galvanized flashing.
 - Galvanized staples may be used to temporarily hold flashing in place until project is sided and decked
- * **CAUTION:** polymer backing is an integral part of the composite material and should not be removed!

- 1** Although YorkShield 106 PT may be used behind the ledger board, best practices suggest using it in front.
- 2** Run YorkShield 106 PT five or more inches upward on the outside wall from top of ledger to prevent water entry to the home.
- 3** Please use hot dipped galvanized fasteners on all outdoor projects; upgrading to stainless steel is recommended.
- 4** (Optional) Use YorkWrap in conjunction with YorkShield 106 PT to further ensure longevity of hangers and project life.

